

Audi Comfort Control Module (CCM) Technical Guide: Wiring Diagrams, Pinout Analysis, and Troubleshooting for C5, C6, and B6 Platforms

Published: May 2, 2025 | Index ID: #944

In the sophisticated ecosystem of Audi electronics, the **Comfort Control Module (CCM)**, also known as the Convenience Control Module, serves as the primary arbiter for cabin-related electronic functions. For engineers, technicians, and dedicated enthusiasts working on the **Audi A6 (C5 and C6)** or the **A4 (B6)** platforms, understanding the intricate wiring and communication protocols of the CCM is essential for maintaining vehicle integrity. This technical guide provides an exhaustive analysis of CCM architecture, wiring configurations, and diagnostic methodologies required to resolve complex electrical faults.

1. The Functional Architecture of the Audi Comfort System

The CCM is not merely a relay box; it is a dedicated microcontroller-based unit that interfaces with the vehicle's **Controller Area Network (CAN Bus)**. Its primary responsibility is to manage high-impedance signals from various sensors and switches to actuate high-current devices like window motors, central locking solenoids, and interior lighting arrays. In the **Audi C5 A6**, the module is typically located in a protective plastic housing under the carpet on the driver's side (or passenger side in RHD models), a location that makes it susceptible to environmental factors such as moisture and physical stress.

The system operates on a master-slave topology where the CCM acts as the master for the **Convenience CAN**. It communicates with door control modules (located inside each door) which handle specific local tasks like window regulator positioning and mirror adjustments. This decentralized approach reduces the sheer bulk of the wiring harness while increasing the complexity of the diagnostic process.

2. Core Technical Components and Mechanisms

The CCM's operation is predicated on three core pillars of automotive electronics: **Power Distribution**, **Ground Logic**, and **Data Communication**. To effectively troubleshoot a unit, one must understand how these components interact within the module's circuitry.

2.1 Power Rails and Terminal Logic

Audi's wiring standard follows the **DIN 72552** terminal designation system. For the CCM to function, it requires several distinct power inputs:

- Terminal 30: Constant 12V battery power. This is required for memory retention, the alarm system, and remote keyless entry reception when the ignition is off.
- Terminal 15: Switched 12V power (Ignition On). This signals the module to enter an active state and enables high-draw functions like power windows.
- Terminal 31: Chassis ground. A solid ground connection is the most frequent point of failure in CCM circuits, often leading to "ghost" signals or erratic behavior.

2.2 The Role of the Red Connector (T15)

As noted in technical forum discussions regarding the **C5 A6**, the red connector (often designated as T15) is a

critical interface point. This connector typically handles secondary convenience inputs, including hatch/trunk release triggers, alarm horn outputs, and the integration with the **Brake Light/ESP**circuit. A break in a single wire on this connector can cause a cascade of seemingly unrelated failures, such as the ESP light illuminating on the dashboard simultaneously with the failure of the interior dome lights.

3. Technical Comparison of CCM Generations

The evolution from the C5 to the C6 and B6 platforms saw significant shifts in module integration and part numbering (such as the transition toward the **4H0907064H**series in later models). The following table outlines the key differences in system architecture.

Feature	Audi A6 (C5) / A4 (B6)	Audi A6 (C6) / A8 (D3)	Modern Audi (C7/C8)
Module Name	J429 (Central Locking) / J393	J393 (Convenience System)	BCM2 (Body Control Module 2)
Communication	K-Line & Low-Speed CAN	High-Speed CAN Bus	FlexRay & CAN-FD
Typical Location	Floorboard (Under Carpet)	Right side of Trunk/Boot	Right side of Trunk/Boot
Diagnosis Tool	VAG-COM / VCDS (K-Line)	VCDS / ODIS (CAN)	ODIS (UDS Protocol)
Component Protection	No	Yes (Software Lock)	Yes (Enhanced)

4. In-Depth Wiring Analysis and Pinout Identification

When analyzing a wiring diagram for the **Audi A4 B6** or **A6 C5**, technical writers and mechanics must prioritize the identification of the multi-pin connectors. The CCM typically utilizes between three to five distinct connectors, color-coded for ease of installation but often prone to confusion during harness repair.

4.1 Standard Pinout Logic (Illustrative Example)

While specific pinouts vary by VIN and production year, the following logic generally applies to the 15-pin and 12-pin central connectors found in the C5/B6 convenience modules:

- Pin 1 (Red/Blue): Permanent positive connection (Terminal 30).
- Pin 2 (Brown): Ground (Terminal 31).
- Pin 3 (Orange/Green): CAN-High (Convenience).
- Pin 4 (Orange/Brown): CAN-Low (Convenience).
- Pin 5-8: Door contact switch inputs (Signal goes low when door is opened).
- Pin 12 (Black/Blue): Ignition 12V (Terminal 15).

In cases where a wire is broken off at the connector, as frequently reported in technical forums, the technician must use a digital multimeter to verify the signal type. A floating voltage of approximately 5V-12V usually indicates a pull-up resistor circuit for a switch, whereas a 0V reading might indicate a ground-side control wire.

5. Procedural Guide: Diagnosing a Non-Responsive CCM

If the windows, sunroof, and interior lights fail simultaneously, the CCM is the primary suspect. Follow this rigorous diagnostic workflow to isolate the root cause.

Step 1: Physical Inspection and Water Ingress Audit

Because the C5 and B6 modules are located on the floor, they are victims of clogged **plenum chamber drains**. When water overflows from the battery tray area, it enters the cabin through the ECU box or cabin filter housing. Use a moisture meter or perform a tactile inspection of the foam padding beneath the carpet. If moisture is detected, the module must be removed and inspected for "green crusties" (copper carbonate oxidation) on the PCB and pins.

Step 2: Voltage Drop Testing

Check for 12V at the main power pins using a load-probed test light or multimeter. A multimeter alone may show 12V even through a high-resistance (corroded) connection, but a load-probed light will fail to illuminate if the wiring

cannot carry the necessary amperage. Perform a **voltage drop test** on the ground wire; any reading above 0.1V suggests a compromised ground point at the A-pillar.

Step 3: CAN Bus Integrity Check

Using an oscilloscope, probe the Orange/Green and Orange/Brown wires. You should see mirrored square wave patterns. If one line is pulled to ground or shorted to high, the CCM will enter "Single-Wire Mode" or fail to communicate entirely, leading to a "No Communication" error in VCDS.

6. Troubleshooting Case Studies

Case Study A: The "Sunroof Ghost" on an A4 B6

Symptoms: Sunroof opens randomly; interior lights flicker; VCDS reports "Supply Voltage Too Low." **Investigation:** Inspection of the CCM harness revealed that the **Red/Black power wire** had oxidized inside its crimp terminal. While it looked connected, it had a resistance of 450 ohms. **Solution:** The terminal was de-pinned, the wire was stripped back to clean copper, and a new gold-plated terminal was crimped. Normal operation was restored.

Case Study B: ESP and Brake Light Correlation

Symptoms: A 2005 C6 Avant exhibits ESP errors and non-functional rear hatch release. **Investigation:** The wiring diagram suggested a shared path between the CCM's convenience logic and the brake light suppression circuit. A short circuit was found in the **flexible wiring bellows** of the rear hatch. **Solution:** Repairing the fractured wires in the hatch bellows cleared the CCM faults and resolved the ESP dash light, illustrating how body-control faults can migrate to chassis-control systems.

7. Advanced Modification: Bypassing the CCM?

A common question in the technical community is whether the CCM can be bypassed. From an engineering standpoint, **bypassing is not feasible** for a street-legal vehicle. The CCM handles the **Immobilizer (IMMO)** handshaking in many models, meaning the engine will not stay running if the CCM is bypassed. Furthermore, the complexity of the integrated alarm and central locking would require a massive array of manual toggles and relays to replicate, compromising vehicle safety and security.

The only viable alternative to a new unit is a used module with matching part numbers. However, on later models like the C6, "Component Protection" must be cleared by a dealer or a technician with access to the **Audi Online Connection (GEKO)** system, as the module is digitally VIN-locked to the vehicle's Gateway.

8. Mathematical Model for Diagnostic Thresholds

Technicians can use a basic mathematical approach to determine if a CCM is drawing excessive current (indicative of an internal short). The **Quiescent Current Draw** of a healthy Audi CCM after the CAN Bus has entered "Sleep Mode" (usually 15-30 minutes after key-off) should follow this formula:

$$I_{total} = I_{ccm} + I_{door_modules} + I_{instrument_cluster}$$

In a standard configuration:

I_{total} should be < 0.040 Amperes (40mA).

I_{total} > 0.100A, pull the CCM fuse. If the draw drops, the module is failing to "sleep" or has an internal parasitic leak.

9. Maintenance and Preventive Strategies

To ensure the longevity of the Audi Comfort System, proactive maintenance is required. First, the **sunroof drains** and **cowl drains** must be cleared of debris every six months. A simple test involves pouring water into the sunroof channel and ensuring it exits quickly behind the front wheels. Second, if any moisture is ever detected in the footwell, the CCM should be immediately elevated or the area dried with a dehumidifier to prevent capillary action from pulling water into the wire harness.

Finally, when performing any electrical work, always disconnect the battery. High-voltage spikes during jump-starting or improper charging can easily blow the sensitive **transceiver chips** within the CCM, leading to permanent communication failure. By adhering to these technical protocols and utilizing the wiring diagrams provided in official workshop manuals, owners can maintain the sophisticated comfort features that define the Audi driving experience.

The CCM remains a masterpiece of late-90s and early-2000s automotive engineering, acting as the silent conductor of the vehicle's convenience orchestra. Whether you are pin-tracing a 2000 A6 or coding a 2012 Quattro, precision and technical accuracy are the only paths to a successful repair.

Baca Juga (Artikel Terkait)

- [Comprehensive Guide to Cylinder Head Spacer Shims: Engineering Principles and Precision Installation](http://alaskawriters.com/cylinder-head-spacer-shims-engineering-guide.pdf)

URL: <http://alaskawriters.com/cylinder-head-spacer-shims-engineering-guide.pdf>

- [The Comprehensive Technical Guide to Ford Focus TDCi Engines: Architecture, Management, and Maintenance](http://alaskawriters.com/ford-focus-tdci-engine-technical-guide.pdf)

URL: <http://alaskawriters.com/ford-focus-tdci-engine-technical-guide.pdf>

- [The Engineering Mastery of VTEC Turbo: A Comprehensive Technical Analysis of Honda's Forced Induction Evolution](http://alaskawriters.com/technical-analysis-honda-vtec-turbo-engineering.pdf)

URL: <http://alaskawriters.com/technical-analysis-honda-vtec-turbo-engineering.pdf>

- [Comprehensive Guide to Volkswagen Jetta Engine Diagrams: Technical Specifications, Maintenance, and Component Analysis](http://alaskawriters.com/comprehensive-volkswagen-jetta-engine-diagram-technical-guide.pdf)

URL: <http://alaskawriters.com/comprehensive-volkswagen-jetta-engine-diagram-technical-guide.pdf>

Tags: [#Audi CCM](#) [#Wiring Diagram](#) [#Audi A6 C5](#) [#Comfort Control Module](#) [#VCDS Diagnostics](#)

